




SPARE PARTS CATALOGUE




MX9000IS

COMPLETE UNIT




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Engine Base Plate Assembly	
2	Engine Assembly	
3	Frame Assembly	
4	Fuel Tank Assembly	
5	Inverter Assembly	
6	Left Side Housing Assembly	
7	Exhaust Housing Assembly	
8	Control Panel Assembly	
9	Rear Housing Assembly	
10	Handle and Wheel Assembly	
11	Battery Assembly	

CHASSIS ASSEMBLY




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Left Panel Assembly	SP9000IS-001
2	Bolt	
3	Left Window Panel Assembly	SP9000IS-002
4	Rubber Sleeve	

AIR OUTLET BOARD




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Exhaust Heat Shield	SP9000IS-003
2	Exhaust Louver	SP9000IS-004
3	Screws	
4	Bolt	
5	Clip Nut	
6	Wire Clamp	
7	Exhaust Housing Assembly	SP9000IS-005
8	Start Protection Ring	SP9000IS-006
9	Screws	
10	Oil Port Repair Cover Assembly	SP9000IS-007

MOVEMENT ASSEMBLY




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Engine Component	SP9000IS-008
2	Muffler Lower Hood Assembly	SP9000IS-009
3	Bolt	
4	Bolt	
5	Exhaust Gasket	
6	Muffler Assembly	SP9000IS-010
7	Spring Washer	
8	Nut	
9	Muffler Lower Cover Plate	
10	Bolt	
11	Plain Washer	
12	Bolt	
13	Muffler Upper Hood Assembly	SP9000IS-011
14	Bolt	
15	Plain Washer	
16	Muffler Outlet Rubber Sleeve	SP9000IS-012
17	Alternator Air Rubber Sleeve	SP9000IS-013
18	Air Filter Intake Rubber Sleeve	SP9000IS-014

FUEL TANK




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Fuel Tank Assembly	SP9000IS-015
2	Plain Washer	
3	Bolt	
4	Bolt	
5	Fuel Tank Cover Assembly	
6	Fuel Tank Rubber Cover	
7	Sealant Sleeve	

BACK SHIELD




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Bolt	SP9000IS-016
2	Rear Cover Assembly	
3	Screws	
4	Rear Soundboard	

CONTROL PANEL




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Bolt	
2	Control Panel Assembly	SP9000IS-017
3	Front Cover Assembly	SP9000IS-018
4	Bolt	
5	Front Soundboard	SP900IS-019
6	Screws	

INVERTER




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	inverter Bracket	
2	Bolt	
3	Inverter Wing Scooper Assembly	SP9000IS-020
4	Bolt	
5	Inverter Component	SP900IS-021
6	Bolt	

HANDLE BAR AND WHEEL ASSEMBLY




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Rubber Cover for Handle	SP9000IS-022
2	Handle	
3	Handle Fixing Seat, Left	
4	Handle Fixing Seat, Right	
5	Bolt	
6	Bushing	
7	Bolt	
8	Button	
9	Spring	
10	Bolt	
11	Wheel	SP9000IS-013
12	Plain Washer	
13	Bolt	
14	Foot Frame	SP9000IS-014
15	Bolt	
16	Vibration Absorbing Rubber Pad	
17	Bolt	

RACK ASSEMBLY




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Upright, A	
2	Upright, B	
3	Upright, E	
4	Upright, F	
5	Cross Beam	
6	Bolt	
7	Fuel Tank Support	
8	Handle	
9	Handle Pin	
10	Bolt	
11	Battery Holder, B	
12	Support Tube Fixing Seat, Left	
13	Bolt	
14	Support Tube Fixing Seat, Right	
15	Fastening Spring	
16	Handle Pin	
17	Fixed Seat Cover, Right	
18	Screws	
19	Handle Block, Right	
20	Screws	
21	Handle Block, Left	
22	Handle Pin	
23	Support Tube Assembly	
24	Bolt	
25	Plain Washer	

ENGINE BASE BOARD




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Support Plate	
2	Nut	
3	Damping Mount	SP9000IS-015
4	Screws	
5	Dust Shield	
6	Bottom Plate	
7	Bolt	
8	Bolt	
9	Engine Base Plate, Left	
10	Nut	
11	Engine Base Plate, Right	
12	Bolt	
13	Battery Holder	SP9000IS-016
14	Clip Nut	

ENGINE PARTS



NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Pin	
2	Bolt	SP900IS-020
3	Fan	
4	Rotor	SP900IS-036
5	Plain washer	
6	Nut	
7	Screws	
8	Stator	SP900IS-035
9	Pin	
10	Alternator end cover	
11	Bolt	SP900IS-020
12	Plug	

BATTERY ASSEMBLY



NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Wire Harness Assembly	SP9000IS-017
2	Battery	SP9000IS-018
3	Battery Band	SP9000IS-019

SPARE PARTS AND SERVICING

WHERE DO I TAKE MY PRODUCT FOR SERVICE OR REPAIR?

Please contact MaxWatt at customercare@maxwatt.com.au we can provide after-sales support for your generator.

Should you experience any problems with your generator, it is recommended that you consult the troubleshooting guide in the Instruction Manual first before contacting us. The most common issues can be resolved quickly in this manner without the inconvenience of having to take your generator to a service agent.

ARE SPARE PARTS AVAILABLE FOR PURCHASE?

Yes, we carry a full range of spare parts for all products. Please check our catalogue for a full list of spare parts and contact us if you need to order anything.

Distributed by:



Shop 15/1440 New Cleveland Rd, Chandler QLD 4155

(07) 3732 5363

customercare@maxwatt.com.au