

MAXWATT®


POWER WHEN YOU NEED IT

SPARE PARTS CATALOGUE




MX7000ES

COMPONENTS



NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Hexagon Flange Bolt	
2	Motor Tail Cover	
3	Voltage Regulator	SP10218
4	Hexagon Flange Bolt	
5	Hexagon Flange Bolt	
6	Flat Washer	
7	Motor Bracket	
8	Hexagon Flange Bolt	
9	Hex Head Bolt/	
10	Motor Parts	
11	Stator	SP10182
12	Rotor	
13	Binding Post	
14	Carbon Brush	
15	Flat Washer / $\Phi 5 * \Phi 10 * 1$	
16	Spring Washer	
17	Nylon Nut	
18	Replacement Engine	SP10219
19	Air Filter Bracket	
20	Hexagon Flange Nut	
21	Hexagon Flange Nut	
22	Flat Washer	
23	Supporting Parts	
24	Hexagon Flange Bolt	
25	Hexagon Flange Bolt	
26	Silencer Gasket	
27	Spring Washer	
28	Hex Nut / M8 *	
29	Muffler Parts	
30	Shield	
31	Hexagon Flange Bolt	
32	Fuel Tank Gasket	
33	Fuel Tank Assembly	
34	Clamp	
35	Fuel Pipe	
36	Fuel Tank Switch	
37	Control Panel Assembly	SP10220
38	Hexagon Flange Nut	
39	Vibration Damping Support / Lower M8	
40	Rack Assembly	
41	Single Head Bolt Vibration Damping Seat	
42	Plum-Shaped Spring Pad	
43	Harness Parts	
44	Rack Damping Pad	
45	Battery	SP10221
46	Battery Plate	
47	Harness Parts	SP10222
48	Harness Parts	SP10223
49	Crankcase Cover Baffle	
50	Dustproof Rubber	
51	Plug	
52	Handle Fixing Pin	
53	Handle Tube Assembly	
54	Handle Rubber Sleeve	
55	Hexagon Flange Bolt	
56	Bracket Parts	
57	Damping Rubber Pad	
58	Axle	
59	Flat Washer	
60	Locating Pin Lock Clip	
61	Wheel Assembly	

ENGINE



NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Hexagon Flange Bolt	
2	Cylinder Head Assembly	
3	Clamp	
4	Exhaust Pipe	
5	Cylinder Head Gasket	
6	Hexagon Flange Bolt	
7	Cylinder Head Air Hood	
8	Rocker Shaft Adjusting Nut	
9	Rocker Shaft	
10	Valve Rocker Arm	
11	Rocker Shaft Bolt	
12	Exhaust Valve Rotor	
13	Exhaust Valve Spring Seat	
14	Valve Spring	
15	Exhaust Valve Spring Seat	
16	Oil Seal	
17	Pusher Guide	
18	Hexagon Flange Bolt/	
19	Cylinder Head Assembly	
20	Intake Stud Bolt	
21	Air Inlet Seal	
22	Carburetor Connection Block	
23	Carburetor Gasket	
24	Carburetor Assembly	
25	Air Filter Gasket	
26	Hexagon Flange Nut	
27	Air Filter Assembly	
28	Choke Door Assembly	
29	Rubber Protective Sleeve	
30	Spark Plug Parts	
31	Exhaust Stud Bolt	
32	Positioning Pin	
33	Cylinder Head Gasket	
34	Valve Push Rod	
35	Intake Valve	
36	Exhaust Valve	
37	Valve Tappet	
38	Piston Ring Assembly	
39	Piston	
40	Piston Pin	
41	Piston Pin Snap Ring	
42	Connecting Rod Assembly	
43	Hexagon Flange Bolt	
44	Aluminum Gasket	
45	Wind Guide Floor	
46	Crankcase	
47	Oil Seal	
48	Ignition Coil Assembly	
49	Hexagon Flange Bolt	
50	Flywheel Parts	
51	Fan	
52	Starter Cup	
53	Hexagon Flange Nut	
54	Recoil Starter Assembly	
55	Line Card	
56	Crimp Board	
57	Hexagon Flange Bolts	
58	Starting Motor Parts	SP10227
59	Hexagon Flange Bolt	

60	Charging Coil Parts	SP10228
61	Oil Alarm	SP10229
62	Speed Control Lever	
63	Speed Control Arm Parts	
64	Fine Adjustment Spring	
65	Reset Spring	
66	Speed Controller Assembly	
67	Locating Pin Lock Clip	
68	Swing Rod Gasket/ $\Phi 8 * \Phi 17 * 1.0$	
69	Oil Seal / $\Phi 8 * \Phi 14 * 5$	
70	Adjustable Speed Swing Lever	
71	Hexagon Flange Nut	
72	Oil Sensor	
73	Hexagon Flange Bolts	
74	Lower Air Guide	
75	Deep Groove Ball Bearing	
76	Balance Shaft	
77	Camshaft Assembly	
78	Crankcase Cover Gasket	
79	Crankshaft Assembly	
80	Positioning Pin	
81	Deep Groove Ball Bearing	
82	Speed Control Gear Assembly	
83	Oil Dipstick Assembly	
84	Crankcase Cover	
85	Hexagon Flange Bolts	

NO.	ADDITIONAL PARTS	MAXWATT PART NUMBER
1	Replacement 4 In 1 Meter	SP10224
2	Replacement Keys	SP10225
3	Replacement Air Filter Element	SP10226

SPARE PARTS AND SERVICING

WHERE DO I TAKE MY PRODUCT FOR SERVICE OR REPAIR?

Please contact MaxWatt at customercare@maxwatt.com.au we can provide after-sales support for your generator.

Should you experience any problems with your generator, it is recommended that you consult the troubleshooting guide in the Instruction Manual first before contacting us. The most common issues can be resolved quickly in this manner without the inconvenience of having to take your generator to a service agent.

ARE SPARE PARTS AVAILABLE FOR PURCHASE?

Yes, we carry a full range of spare parts for all products. Please check our catalogue for a full list of spare parts and contact us if you need to order anything.

Distributed by:



Shop 15/1440 New Cleveland Rd, Chandler QLD 4155

(07) 3732 5363

customercare@maxwatt.com.au