




SPARE PARTS CATALOGUE



MXPW3200


NO.	DESCRIPTION	MAXWATT PART
1	Hexagon Socket Head Bolt	
2	Swash Pump Plate	
3	Flat Key	
4	Complete Engine Replacement	SP10127
5	Nozzle 0°	SP10128
6	Nozzle 15°	SP10129
7	Nozzle 25°	SP10130
8	Nozzle 40°	SP10131
9	Nozzle	SP10132
10	Nozzle Holder	
11	Hexagon Socket Head Bolt	
12	Nozzle Panel	
13	High Pressure Pipe Hook	
14	Handle Tube Assembly	
15	Plastic Handle	
16	Gun Frame Assembly	SP10133
17	Hexagon Flange Bolts	
18	Flat Washers	
19	Nylon Nut	
20	Swivel Arm	
21	Rack Components	
22	Wheel Parts	SP10134
23	Axle	
24	Locating Pin Lock Clip	
25	Flat Washers	
26	Damping Pad	
27	Hexagon Socket Head Bolt	
28	Hexagon Flange Bolts	
29	Flat Washers	
30	Water Tank	SP10135
31	Radiator Cap	SP10120
32	Hexagon Flange Nut	
33	Stud Damping Seat	
34	Spray Gun	SP10136
35	Pipette	
36	Clamp	
37	Boom	
38	Inlet Pipe	
39	High Pressure Pipe	SP10137

PUMP ASSEMBLY



NO.	DESCRIPTION	MAXWATT PART
1	A Kit	SP10121
2	B Kit	SP10122
3	C Kit	SP10123
4	D Kit	SP10124
5	F Kit	SP10125
6	Complete Pump Replacement	SP10126


CYLINDER HEAD



NO.	DESCRIPTION	MAXWATT PART
1	Bolt Flange	
2	Cover Comp Head	
3	Head Cover Packing	
4	Exhaust Pipe	
5	Bolt Flange	
6	Spark Plug	
7	Shroud	
8	Bolt Flange	
9	Spring Collar	
10	Exhaust Pipe	
11	Exhaust Pipe	
12	Bolt Stud Exhaust	
13	Cylinder Head Complete	
14	Cylinder Gasket	
	Cylinder Gasket	
15	Dowel Pin	
16	Bolt Stud Intake	


SP10138

CRANKCASE ASSEMBLY




NO.	DESCRIPTION	MAXWATT PART
1	Bolt Flange	
2	Bearing	
3	Engine Oil Sensor	SP10139
4	Governor Gear Kit	SP10140
5	Bolt, Washer, Drain Plug	SP10141
6	Washer	
7	Crankcase	
7	Crankcase	
8	Oil Seal	SP10142
9	Washer	
10	Pin Lock	
11	Governor Arm Shaft	

CRANKCASE COVER




NO.	DESCRIPTION	MAXWATT PART
1	Oil Seal	SP10143
2	Cap Assembly	SP10144
3	Washer	
4	Flange Bolt	
5	Crank Case Cover	
6	Washer	
7	Cap Assembly	SP10145
8	Bearing	
9	Dowel Pin	SP10146
10	Crank Case Cover Gasket	SP10147

CRANKSHAFT AND PISTON




NO.	DESCRIPTION	MAXWATT PART
1	Ring Set Piston	SP10148
2	Clip Piston Pin	
3	Piston	
4	Piston Pin	
5	Connecting Rod Assembly	SP10149
6	Bolt Flange	
7	Crankshaft Assembly	SP10150
8	Woodruff Key	

ROCKER/VALVES/CAMSHAFT




NO.	DESCRIPTION	MAXWATT PART
1	Unit Pivot Adjusting	SP10160
2	Pivot Rocker Arm	
3	Rocker Arm	
4	Pivot Bolt	
5	Push Rod Plate Guide	
6	Rotator Valve	SP10161
7	Valve Spring Retainer	
8	Valve Spring Retainer	
9	Spring Valve	
10	Oil Shield	
11	Exhaust Valve	
12	Intake Valve	
13	Push Rod	
14	Valve Lifter	SP10162
15	Camshaft Assembly	

CARBURETTOR




NO.	DESCRIPTION	MAXWATT PART
1	Insulator Packing	
2	Carb Insulator	
3	Carb Insulator	
4	Carburetor	SP10163

RECOIL STARTER




NO.	DESCRIPTION	MAXWATT PART
14	Complete Recoil Starter	SP10164

CONTROL ASSEMBLY




NO.	DESCRIPTION	MAXWATT PART
9	Control Assembly	SP10165

FLYWHEEL




NO.	DESCRIPTION	MAXWATT PART
1	Engine Switch Wire	SP10166
2	Ignition Coil Assembly	SP10167
3	Flange Bolt	
4	Noise Suppressor Cap Assembly	
5	Complete Flywheel	SP10168
6	Cooling Fan	SP10169
7	Starter Pulley	SP10170
8	Nut	

AIR CLEANER




NO.	DESCRIPTION	MAXWATT PART
1	Butterfly Bolt	
2	Air Cleaner Cover	
3	Butterfly Nut	
4	Air Cleaner Element Assembly	SP10171
5	Elbow	
6	Silencer	
7	Breather Tube	
8	Air Cleaner Plate	
9	Complete Air Cleaner Elbow	
10	Air Cleaner Assembly	SP10172
11	Tube Clip	
12	Flange Nut	

MUFFLER



NO.	DESCRIPTION	MAXWATT PART
1	Hex Nut	SP10173
2	Spring Collar	
3	Muffler Assembly	
4	Muffler Gasket	

FUEL TANK



NO.	DESCRIPTION	MAXWATT PART
4	Fuel Tank Assembly	SP10174
5	Fuel Cap	
6	Fuel Filter	
7	Complete Fuel Tank	

SPARE PARTS AND SERVICING

WHERE DO I TAKE MY PRODUCT FOR SERVICE OR REPAIR?

Please contact MaxWatt at customercare@maxwatt.com.au we can provide after-sales support for your generator.

Should you experience any problems with your generator, it is recommended that you consult the troubleshooting guide in the Instruction Manual first before contacting us. The most common issues can be resolved quickly in this manner without the inconvenience of having to take your generator to a service agent.

ARE SPARE PARTS AVAILABLE FOR PURCHASE?

Yes, we carry a full range of spare parts for all products. Please check our catalogue for a full list of spare parts and contact us if you need to order anything.

Distributed by:



Shop 15/1440 New Cleveland Rd, Chandler QLD 4155

(07) 3732 5363

customercare@maxwatt.com.au