




SPARE PARTS CATALOGUE




MXPW3500

MACHINE COMPONENTS




NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Engine assy.	MXPW3500-001
2	Hige pressure hose hanger	MXPW3500-002
3	Hexagon socket head bolt	
4	Hexagon socket head bolt	
5	Storage panel	MXPW3500-003
6	0° Nozzle	MXPW3500-004
7	15° Nozzle	MXPW3500-005
8	25° Nozzle	MXPW3500-006
9	40° Nozzle	MXPW3500-007
10	Nozzle	MXPW3500-008
11	Nozzle holder	MXPW3500-009
12	Nylon nut	
13	Foam grip	MXPW3500-010
14	Handle tube assy.	MXPW3500-011
15	Gun holder assy.	MXPW3500-012
16	Triplex pump	MXPW3500-013
17	Hexagon socket cylindrical head bolt	
18	Flat key	
19	V-clip	
20	Frame assy.	MXPW3500-013
21	Wheel assy.	MXPW3500-014
22	Flat washer	
23	Damping pad	MXPW3500-015
24	Hexagon socket head bolt	
25	Hex flange nut	
26	Stud damping seat	
27	Axle	MXPW3500-016
28	Locking clip of locating pin	
29	Spray gun	MXPW3500-017
30	Spray wand	MXPW3500-018
31	High pressure hose	MXPW3500-019

PUMP ASSEMBLY



NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Head Assembly	
2	Head	
3	O-ring Ø 8,1,1	
4	Plug	
5	Valve Thermal	
6	Plug	
7	O-ring Ø 13,5,1,8	
8	Complete Valve Brass	
9	Fitting 3/8" (G M)	
10	O-ring Ø 12,4x1,78	
11	O-ring Ø 12,1	
12	O-ring Ø 9,1	
13	Injector Ø 2,0	
14	Spring	
15	Shutter	
16	O-ring Ø 4,2,5	
17	Hose Tail Ø 8	
18	O-ring Ø 4,48,1,78	
19	Ball	
20	Spring	
21	O-ring Ø 8,1,1	
22	Water Seal	
23	Bushing Ø 12	
24	O-ring	
25	Bushing Rear Ø 12	
26	Oil Seal	
30	Screw	
31	Knob M16.1	
32	Nut	
33	Screw STEI M3,4	
34	Screw	
35	Spring	
36	Wobble Plate	
37	Piston	
38	O-ring Ø 6,02,2,62	
39	O-ring Ø 6,07,1,78	
40	Ring Anti-Rotation	
41	Piston Guide	

ENGINE EXPLODED VIEW



NO.	DESCRIPTION	MAXWATT PART NUMBER
1	Bolt	
1	Bolt	
2	Cylinder Head Cover Assembly	
3	Clamp	
4	Bolt	
4	Bolt	
4	Bolt	
4	Bolt	
5	Wing Scooper	
6	Cylinder Head Cover Gasket	
7	Air Lock Clamp	
8	Valve Spring Seat	
9	Valve Spring	
10	Intake Valve Oil Shield	
11	Nut	
12	Swing Arm Shaft	
13	Swing Arm For Valve	
14	Swing Arm Shaft Bolt	
15	Push Rod Plate	
16	Bolt	
17	Cylinder Head Assembly	
18	Muffler Gasket	MXPW3500-020
19	Spark Plug Parts	MXPW3500-021
20	Bolt	
21	Exhaust Stud	
22	Spring Washer	
23	Nut	
24	Muffler Component	MXPW3500-022
25	Pin	
26	Inlet Valve	
27	Exhaust Valve	
28	Cylinder Head Gasket	
29	Pushing Rod For Valve	
30	Rod For Valve	
31	Piston Ring Assembly	
32	Piston	
33	Piston Pin	
34	Clip Cycle	
35	Connecting Rod Assembly	
36	Bolt	
37	Aluminium Gasket	
38	Crankcase	
39	Oil Seal	
40	Bolt	
41	Ignition Coil Unit	MXPW3500-023
42	Oil Alarm	MXPW3500-024
43	Wire Clip	
44	Clipping Pipe	MXPW3500-025
45	Fly Wheel	
46	Fan	
47	Starting Cup	
48	Side Windshield	
49	Switch	MXPW3500-026
50	Nut	
51	Recoil Starter Assembly	MXPW3500-027
52	Nut	
53	Air Filter Assembly	MXPW3500-028
	Air Filter Element	MXPW3500-029
54	Clamp	
55	Fuel Pipe	MXPW3500-030
56	Air Intake Stud	
57	Air Intake Gasket	
58	Carburetor Connection Block	
59	Carburetor Washer	MXPW3500-031
60	Carburetor Assy	
61	Air Filter Gasket	MXPW3500-032
62	Shaft, Governor	
63	Locating Pin Lock Clamp	
64	Pendulum Rod Gasket	
65	Oil Sensor	MXPW3500-033
66	Bearing	
68	Camshaft Assembly	
69	Crankshaft Assembly	
70	Crankcase Cover Gasket	
71	Crankcase Cover	
72	Bolt	
73	Oil Plug Assembly	MXPW3500-034
74	Dipstick	MXPW3500-035
75	Pin	
76	Speed Control Gear Assembly	MXPW3500-036
77	Governor Assembly	
78	Reset Spring	
79	Trimmer Spring	
80	Speed Regulating Rod	
81	Governor Arm Unit	
84	Bolt	

SPARE PARTS AND SERVICING

WHERE DO I TAKE MY PRODUCT FOR SERVICE OR REPAIR?

Please contact MaxWatt at customercare@maxwatt.com.au we can provide after-sales support for your generator.

Should you experience any problems with your generator, it is recommended that you consult the troubleshooting guide in the Instruction Manual first before contacting us. The most common issues can be resolved quickly in this manner without the inconvenience of having to take your generator to a service agent.

ARE SPARE PARTS AVAILABLE FOR PURCHASE?

Yes, we carry a full range of spare parts for all products. Please check our catalogue for a full list of spare parts and contact us if you need to order anything.

Distributed by:



Shop 15/1440 New Cleveland Rd, Chandler QLD 4155

(07) 3732 5363

customercare@maxwatt.com.au